



Storing De display shows message [ME01 Fill and place water tank] or [flow error].


Actie Check placement of the water tank, and correct/replace.



Check if (drinking) water is present in the water tank. (Re)fill if necessary.



Is the tank placed upright, and does the lower edge fully align with the edge of the machine as shown here?



If not, correct the position of the water tank: lift the tank, and lower it once more to ensure that it placed upright.



If the machine is not placed upright, the water outlet of the tank does not connect properly to the water inlet at the machine side. This will trigger a [flow error] message in the display.



Do you have any questions, or does the problem persist? Please contact the helpdesk of your local service organization.