

Excellence Compact Touch

Troubleshooting



Problem: Message [Water filling takes too long]

Action: Check the water supply.

Background : the internal boiler is not filled within the designated time. This is most likely caused by a disrupted water supply.



Check if the water tap is opened. (Also check if there is water pressure elsewhere on your location)



Check if the water filter is fully opened if present (For an Everpure filter: press the black lever down.)



Check if the water descaling filter: is fully opened if present (For a Brita filter, press the blue lever to the horizontal position.



Do you have any questions or does the problem persist? Please contact the helpdesk of your local service organization.