

8.2 Brewer malfunction (Error 04104)

Brewer motor not moving.

When no movement is detected the error message is displayed, see 8.2a.


- *The brewer axis cannot be turned manually nor with tools.*

8.2a



Information message:
• press > to begin the reset

8.2b



- open the side panel as shown on the screen
- *When the side panel is removed, the next screen will appear.*

8.2c



Information screen:
• follow the screen instructions
• press > to go to the next screen




8.2d


Check if the complete brewer can be placed:

- press < or > to choose no/yes
- press **start** to confirm

- ▶ *selected YES:
next screen is 8.2m*
- ▶ *selected NO:
go to the next step*




8.2e



- press < or > to choose the direction of rotation
- press **start** to confirm



8.2f





- ▶ *The side panel must be closed, otherwise there is a risk of injury from rotating parts.*
- close the side panel as shown on the screen
- ▶ *When the side panel is back in place, the next screen will appear.*



8.2g

- press **start** (and hold) to rotate the axis
- press > to go the next screen

8.2h




- open the side panel as shown on the screen
- ▶ *When the side panel is removed, the next screen will appear.*

8.2i



- Can the brewer be placed:
- press < or > to choose no/yes and
 - press **start** to confirm
 - ▶ *selected NO:*
next screen is 8.2i
 - ▶ *selected YES:*
next screen is 8.2m

8.2j



- Information screen:
- follow the screen instuctions
 - press > to go to the next screen

8.2k




- Check if the complete brewer can be placed:
- press < or > to choose no/yes
 - press **start** to confirm
 - ▶ *selected NO:*
go to the next step
 - ▶ *selected YES:*
next screen is 8.2m

Information screen:

- press > to go to screen 8.2e



8.2l



- close the side panel as shown on the screen
- *When the side panel is back in place, the 'beverage selection screen' will appear.*

8.2m

CIRCO brewer reset has finished



8.2n


9.Warning and errors messages

9.1 Warning messages

Warning messages are used to inform the operator of a state which can prevent the Sprso from working correctly. In general warning messages are displayed after beverage.

- *The warning messages are displayed for 30 seconds.*
- A message can be displayed again when any button (except menu button) is used.*
- The menu will remain available.*



Example screen for warning messages



9.1a

Nr	Message	Description	Reset condition
ME01	fill or place water tank	no water detected in water tank or water tank not present	• fill water tank or place water tank in correct position
ME02	not applicable		
ME03	close side panel	service panel not in correct position	• close service panel (in correct position)
ME04	place drip tray + waste bin	waste bin not in place	• place drip tray with waste bin (in correct position)
ME05	empty waste bin The icon below is visible on the 'beverage selection screen'.	the waste bin is full and must be emptied or waste bin counter exceeded	• remove the drip tray. Empty the waste bin and drip tray. Put the parts back in the correct position
ME06	not applicable		



Nr	Message	Description	Reset condition
ME07	clean milk system daily	will be displayed when coffee flush or startup flush is active and a milk unit is activated in the software	<ul style="list-style-type: none"> only a reminder
ME08	clean brewer The icon below is visible on the 'beverage selection screen'. 	start cleaning coffee system or continue (the first message is displayed after 125 brewing cycles - the message is repeated after every beverage until the brewer is cleaned)	<ul style="list-style-type: none"> after the 'clean coffee system' is finished (see section 7.1.3 on page 25)
ME09	replace water filter The icon below is visible on the 'beverage selection screen'. 	please replace water filter for the optimal coffee or continue (the message appears after "XX" litres have passed through the water counter and is repeated after every 11 beverages)	<ul style="list-style-type: none"> replace the water filter and confirm this (see section 7.1.6 on page 35)
ME10	descale machine	descale the machine to keep the system maintained well, not descaling will eventually result in a blocking of the water system or defective parts (the message is repeated after every 9 beverages)	<ul style="list-style-type: none"> descale the Sprso (see section 7.1.5 on page 30)
ME11	not applicable		
ME12	brewer jammed by grinding or obstruction	brewer is blocked. too much coffee ground in the brewer or an obstruction	<ul style="list-style-type: none"> remove the obstruction